## PERIODIC CHECKING OF PERSONAL PROTECTIVE EQUIPMENT SWIVELS



DEVICE IDENTIFICATION SHEET				
Trademark	<u>CT</u> )	Manufacturer	Aludesign S.p.A. Via Torchio 22, 24034 Cisano B.sco (BG) ITALY	
Reference standards	/			

PARTS IDENTIFICATION		
PRIMARY ELEMENTS	Body.	
SECONDARY ELEMENTS		
REPLACEABLE PARTS		

Fill-out this inspection sheet following the inspection procedure, photographs and instructions supplied by the manufacturer, which you can download from <a href="https://www.climbingtechnology.com">www.climbingtechnology.com</a>. Attention! The examiner's verdict on the severity of the anomaly must be based on objective <a href="https://criteria.org/received">criteria and the specific training received</a>. The producer accepts no responsibility deriving from inexact information recorded by the user or <a href="https://services.org/received">services</a>.

## **DEVICE PERIODIC CHECK SHEET** 1) HISTORY AND GENERAL CHECK 1.1 Check the existence and the readability of the marking details, in particular the CE symbol and the applicable EN norm/standard. 1.2 Check that device has not exceeded the storage and/or in-use lifetime, as stated in the specific instructions for use. 1.3 Check that the device is intact and no parts are missing (check against a new product). Check that the device has not been modified outside the factory or serviced in a non-approved centre (check against a new 1.4 product). 1.5 Check that the device has not experienced an exceptional event (e.g. fall from height, violent blow, etc.). Even in the absence of visible defects or deterioration, the original strength could be seriously reduced. 2) VISUAL CHECK 2.1 CHECKING THE BODY

Andre sure there are no suite exacts or share edges. Make sure there are

Make sure there are no cuts, cracks or sharp edges. Make sure there are no incisions deeper than 1 mm. Make sure that areas of wear are no deeper than 1 mm, paying particular attention to where the connectors are in contact with the device. Check there is no corrosion or oxidation.

## 3) FUNCTIONAL CHECK

3.1 MOBILITY OF THE COMPONENTS

Check that the rotation of the components is smooth and without jamming. If necessary, clean it with compressed air, wash with water and soap, dry and lubricate exclusively with silicon oil spray.

The examiner's verdict on the severity of the anomaly must be based on objective criteria and the specific training received. The producer accepts no responsibility deriving from inexact information recorded by the user or servicer.



## **PHOTO APPENDIX** SWIVELS





Body presenting a sign of cut deeper than 1 mm next to the clipping point.





Remains of material that hinder the rotation of the swivel.

Clean up with compressed air, wash with water and soap, lubricate exclusively with silicon oil spray. In case the problem cannot be settled, discard the device.